



Discover your next Mecmesin force and torque display online – visit mecmesin.com/vfti



S.I. Instruments
256 South Rd. Hilton
South Australia 5033
Ph (08) 8352 5511

info@si-instruments.com.au
www.si-instruments.com.au

+44 (0)1403 799979 | mecmesin.com | info@mecmesin.com

DS-1179

VFTI

touchscreen force and torque indicator

Ground-breaking digital force and torque display combining intuitive touchscreen control with sophisticated measurement features - powered by Vector OS.





VFTI Touchscreen Force and Torque Indicator

A versatile handheld touchscreen instrument built for tough environments that delivers accuracy and reliability.

Compatible with our range of external plug-and-play 'Smart Sensors' (using a Smart Adaptor) for a wide range of tension, compression and torsion testing.

Connects to our manual and motorised test stands for greater control of test conditions such as speed and force.



VFTI Touchscreen Force and Torque Indicator



Sensors

Choose from a range of interchangeable 'Smart' force and torque sensors. The VFTI automatically recognises calibration data



Battery life

Fast-charging lithium-ion battery for more testing and less charging (compared with NiMH batteries)



Alarms

Enhanced alarm configurations - including a 'pre-alert' warning for operators as load is applied



Statistics

Use onboard statistics to save peak readings and perform basic statistical analysis onscreen



Visualisation

Powerful data analysis with live graphing and configurable values - pinch or drag to zoom or pan test result graphs



Touchscreen

Easy to use icons and customisable interfaces - swipe or press and hold to access menus and options



Connectivity

USB-C connectivity for charging. RS232 interfacing with VectorPro Lite data capture and analysis, external printers and data loggers



Expansion

Up to 32GB external storage with dynamic data logging via Micro-SDHC card. All data points are saved in CSV format to suit common applications e.g. Excel

